

Wellbeing® Clinical Type A Wash Basin

Installation and Maintenance Instructions

WB-BSNTYPA-HE



Enware products are to be installed in accordance with the Plumbing Code of Australia (PCA) and AS/NZS3500. Installations not complying with PCA and AS/NZS 3500 may void the product and performance warranty provisions.

Reference should also be made to the Australasian Health Facility Guidelines (AHFG), ABCB and Local Government regulations when considering the choice of, and the installation of these products.

This product must be installed and commissioned by a qualified plumber.

For use with potable water only.


NOTE: Enware Australia advises:

1. Due to ongoing Research and Development, specifications may change without notice.
2. Component specifications may change on some export models.
3. Refer to warranty statement for warranty details - www.enware.com.au/warranty.



I00626_16 Oct 2026

Rev. A.2

DIMENSIONS



All dimensions are subject to tolerance +/- 5 unless otherwise stated.



BASIN WASTE

BASIN FIXING KIT

Not to scale. Dimensions are nominal and subject to normal ceramic manufacturing variations due to the nature of the manufacture of vitreous china.

Components included: basin, fixing kit, waste

INSTALLATION

1. Ensure there is adequate wall structure and suitable reinforcement behind finished wall for basin fixings at the required height position.
2. Prepare water and waste outlet points.
3. Position basin at the required position, level, and mark anchor holes.
4. Pre-drill anchor holes where marked, and install fixing bolts.
5. Mount basin on wall and level. Fit plastic washer, metal washer, then fixing nut on each fixing bolt and secure the basin onto wall. Do not overtighten fixing nut.
6. Install tap and/or waste assembly, and connect plumbing.
7. Seal all basin mounting contact surfaces with high grade anti-bacterial silicone of appropriate colour. Do not use epoxy type adhesives.

CLEANING

Enware Product should be cleaned with a soft damp cloth using only mild liquid detergent or soap and water. Do not use cleaning agents containing a corrosive acid, scouring agent or solvent chemicals. Do not use cream cleaners, as they are abrasive. Use of unsuitable cleaning agents may damage the surface. Any damage caused in this way will not be covered by warranty.



1300 369 273
info@enware.com.au
enware.com.au