

Anti-Bacteria Eye Wash Water Preservative Concentrate

ESS200

Bottle Contents:

Chlorhexidine Gluconate 1% w/v, CAS 18472-51-0, Propylene Glycol
CAS 57-55-6

Uses:

A preservative for clean potable water used in portable self-contained emergency eye wash stations. When mixed as directed, Preservative Solution CHG preserves eye wash station water volumes from a minimum of 15 Litres (8 Gallons) to a maximum of 75 Litres (40 gallons).



Directions:

1. Wear appropriate protective eyewear and gloves for this mixing procedure.
2. Clean portable, self-contained eye wash station with potable water and rinse.
3. Partially fill station with potable water – half capacity is recommended.
4. Add entire contents of 236mL (8oz) Preservative Solution CHG bottle and mix thoroughly.
5. Finish filling the station, according to the instructions supplied with eye wash.
6. Date and initial inspection tag.

It is recommended that the station be cleaned and the water replaced at 4 months or at a period no longer than 6 months (depending on climatic conditions) when using this product. Eye wash station water should be checked weekly, and any particulates or discolouration suggests that the water should be replaced immediately.

All test water should be replaced with clean potable water. Replacement potable water for these tests will not reduce the effectiveness of the Preservative Solution CHG when performed for a period of six months from date of first introduction of the Preservative Solution CHG to the station. Refer to instructions supplied with eye wash station for further testing procedures.

DO NOT USE IF SEAL IS BROKEN OR MISSING.

Warnings:

For use in emergency eye wash stations only. Must be mixed as per directions. Preservative Solution CHG must not be used undiluted or in a solution for any other purpose. Do not change the dilution or add other ingredients. Do not use full strength in the eye. In case of contact with eyes in undiluted form, flush with clean water. If you experience any eye pain, change in vision, continued redness or irritation, or if condition worsens after treatment at eye wash station, immediately consult a physician. Keep this and all chemicals out of reach of children. Store in a cool dry place. Use by date is 3 years from manufacture 0 refer to print on bottle.

Questions: Email us at safety@enware.com.au or
Call +61 2 8536 4000, 9am – 5pm EST Monday-Friday
RE-ORDER CODE: ESS200 (box of 4)

I00415_May 21

Call 1300 369 273
www.enware.com.au

Enware Australia Pty Limited
9 Endeavour Rd Caringbah NSW 2229 Australia
Ph: 02 8536 4000 info@enware.com.au

