

Detention Recess Adaptor

Installation and Maintenance Instructions

DET608
DET608-15EXT



technical data

Working Pressure Range	Min 50 kPa Max 500 kPa
Maximum Static Pressure	800 kPa
Maximum Working Temperature	85°C (Ceramic disc)

Enware products are to be installed in accordance with the Plumbing Code of Australia (PCA) and AS/NZS3500. Installations not complying with PCA and AS/NZS 3500 may void the product and performance warranty provisions.

Reference should also be made to the Australasian Health Facility Guidelines (AHFG), ABCB and Local Government regulations when considering the choice of, and the installation of these products.



This product must be installed and commissioned by a qualified plumber.

For use with potable water only.

NOTE: Enware Australia advises:

- 1. Due to ongoing Research and Development, specifications may change without notice.
- 2. Component specifications may change on some export models.

wall depth adjustment



To choose the correct Enware product, firstly find out the required wall depth dimension A.
Order DET608 or DET608-15EXT. Order DET005 or DET015 Trouble Dome if required.
(Refer to table below.)


Recess Wall Depth (A)	Product Code	Trouble Dome Required	Replacement SBA Code
-3 - 0 mm	DET608	DET015	DET382
2 - 5 mm	DET608	DET005	DET382
7 - 10 mm	DET608	None	DET382
10 - 15 mm	DET608-15EXT	DET015	DET383
15 - 20 mm	DET608-15EXT	DET005	DET383
20 - 25 mm	DET608-15EXT	None	DET383



DET608




DET005




DET015

installation

- All supply lines must be flushed thoroughly to remove debris prior to the installation of this product, as per AS/NZS 3500.1. Strainers (40 mesh) are recommended if debris is an ongoing problem.
 - A pressure reduction valve may be required to comply with the recommended maximum supply pressure and/or balanced pressure requirements.
1. Determine the depth of tap body in wall from the finished wall, and check that the product is suitable for the application.
(Refer to Wall Depth Adjustment on page 2.)
 2. Remove the plastic protective cap, fibre washer and locknut from SBA.
 3. Fit the ceramic disc spindle into the tap body. Use a spanner on the hexagonal flats and tighten until it comes to a firm stop. (max. torque 18Nm)
 4. Fit the red fibre washer against the face of the tap body then fit locknut onto spindle.
 5. Using a 25mm spanner, tighten the locknut. Recommended torque setting is 30Nm.




6. Screw the wall flange onto the SBA until flush with wall. Ensure there is no gap between the wall and the flange.
7. Mark the location of the anti-rotation screw through one of the two anti-rotation screw holes in the flange, being aware to avoid any pipe work in the wall. Remove flange from wall fixture and drill a 5mm diameter hole approximately 10mm deep at the marked location.




8. Turn on water to the tap and test for leaks.
9. Seal any gaps between the wall cut-out and SBA with silicone sealant.
10. Apply a thin bead of silicone sealant to the perimeter of the flange. (Use anti-pick silicone or silicone sealant of appropriate grade as required.)
11. Refit flange onto SBA so that the drilled hole in the wall and the anti-rotation screw hole align. Screw the anti-rotation screw into wall using 2.5mm Allen key. The head of the countersink anti-rotation screw must not sit proud of the flange face when fitted.
Note: For optimum vandal resistance, the anti-rotation screw must be installed.
12. Align the handle on the spline of the spindle, locating the handle in the position wanted – usually with the indicator facing upwards at the closed position.
Push handle onto spline and fix in place with anti-tamper screw using a TT25 Post Torx key. No gaps should be present between the wall flange and the handle.
13. Turn water on and test for leaks and correct operation.

-
14. Fit indicator button onto handle.
To do this, ensure the surface of handle is clean and dry, free of dust, moisture and grease. Peel off the indicator button from its backing paper, taking care not to touch the adhesive side. Place the indicator button onto flat section of the handle, and push the button firmly onto handle.



operation

Turn anti-clockwise to turn on.
Turn clockwise to turn off.



cleaning

Enware products should be cleaned with a soft damp cloth using only mild liquid detergent or soap and water. Do not use cleaning agents containing a corrosive acid, scouring agent or solvent chemicals. Do not use cream cleaners, as they are abrasive. Use of unsuitable cleaning agents may damage the surface. Any damage caused in this way will not be covered by warranty.

troubleshooting

PROBLEM	CAUSE	RECTIFICATION
Tap is dripping water through water outlet	Ceramic discs are worn or damaged. Debris in line.	Remove and inspect SBA. Remove debris and/or replace SBA if damaged.
Handle is hard to turn	Handle is catching on flange. Tap body depth is incorrect.	Reset tap body. Use extended recess SBA.
Wall flange does not screw onto thread of SBA	Tap body is set too far into the wall.	Use extended recess SBA or body extenders. Reset tap bodies.
Wall flange does not screw down onto wall surface	Tap body is set too far out.	Use a trouble dome or flange extender. Reset tap bodies.

product warranty statement - WATTS AUSTRALIA

Effective 27 October 2023

This Warranty Statement applies to products supplied by Australian Valve Group Pty Ltd (ACN 068 227 270) (**AVG**) or Enware Pty Ltd (ACN 662 302 767) (**Enware**) (each of AVG and Enware, a Supplier) and installed within Australia.

Subject to the terms and conditions outlined in this Warranty Statement, each Supplier warrants to its customers that a product supplied by it (**Product**) will be free from all defects in material and workmanship under normal usage for the applicable Warranty Period (as set out in the Warranty Table below). The Warranty Period commences from the date of delivery of the relevant Product.

1. Conditions

The warranty provided under this Warranty Statement will not apply in respect of a Product (or any Product defect, fault or resulting damage) if:

- (a) the Product is not installed and maintained in accordance with the requirements of the applicable laws, standards and codes (including, without limitation to, the National Construction Code Volume Three – Plumbing Code of Australia, associated reference standards as applicable at the time and AS/NZS 3500);
- (b) the Product is not installed and maintained by a qualified technician in accordance with the relevant installation and operation manual and instructions; and
- (c) any Product defect, faulty or resulting damage arises from:
 - (i) failure by you or any other person to follow the relevant manual or instructions (relating to the handling, storage, installation, fitting, connection, adjustment, maintenance or repair of the Product) published or provided by the Supplier;
 - (ii) failure by you or any other person responsible for the fitting, installation, or other work on the Product to follow or conform to applicable laws, standards and codes (including, without limitation to, the AS/NZ 3500 set of Standards, all applicable State and Territory Plumbing Codes, the Plumbing Code of Australia and directions and requirements of local and other statutory authorities);
 - (iii) any parts or components not manufactured by the Supplier (or otherwise not authorised by the Supplier) are installed or combined with the Product, without the prior authorisation of the Supplier; or
 - (iv) any act or circumstance beyond our control including, without limitation to, accident, abnormal use, vandalism, fouling caused by foreign material, damage from adverse water conditions, chemical, acts of God, damage to buildings, other structures and infrastructure and loss or damage during transit or transportation of the Product, or any abuse, misuse, misapplication, improper installation or connection, or improper maintenance or alteration of the Product.

2. Make a claim

To make a claim under this Warranty Statement, you must notify the relevant Supplier in writing within 7 days of any alleged defect in the Product coming to your attention and provide the Supplier with proof of your purchase of the Product to the relevant Supplier:

- (a) If the Product is supplied by **AVG**, please contact AVG by telephone at 1800 284 287, or by email via its online portal <https://www.wattsau.com.au/support>.
- (b) If the Product is supplied by **Enware**, please complete the Product Service Request form (ENF091), which is available on request from our office (see contact details below), or online via <https://www.enware.com.au/warranty-service-form/>. All notifications and accompanying forms must be sent to Enware marked for the attention of Enware, 9 Endeavour Road, Caringbah NSW 2229. Enware can also be contacted by telephone (1300 369 273) or by email (info@enware.com.au).

On receipt of a notification from you of a claim under this Warranty Statement, the relevant Supplier may contact you requesting you provide reasonably additional evidence, information or details about your claim, or requiring that the relevant Product should be returned to the Supplier (in accordance with the Supplier's instructions) for inspection and testing.

Your failure to comply with any such request within a reasonable amount of time may result in your claim under this Warranty Statement being rejected.

3. Our responsibilities

(a) In the event that the Supplier is reasonably satisfied that there is a defect in the relevant Product within the applicable Warranty Period, the Supplier will, at its option, replace the Product, supply an equivalent product or repair the Product, free of charge. Your costs in making a warranty claim under this Warranty Statement, including any costs in relation to freight, collection, delivery and installation, are to be borne and paid by you. However, if in respect of a Product, it is indicated in the Warranty Table that labour support will be provided, and the Supplier is reasonably satisfied that a defect in the Product takes place during the period that labour support will be provided as indicated in the Warranty Table, the Supplier will bear the costs for delivery, repair and installation of the replacement Product (as applicable).

(b) TO THE EXTENT PERMITTED BY LAW AND SUBJECT TO PARAGRAPH 4 BELOW AND THE OPERATION OF THE AUSTRALIAN CONSUMER LAW:

(i) THE WARRANTY SET OUT IN THIS WARRANTY STATEMENT IS GIVEN EXPRESSLY AND IS THE ONLY WARRANTY GIVEN BY THE SUPPLIER WITH RESPECT TO THE RELEVANT PRODUCT;

(ii) THE SUPPLIER MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED;

(iii) THE SUPPLIER HEREBY SPECIFICALLY DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE; AND

(iv) THE REMEDY DESCRIBED IN THIS WARRANTY STATEMENT SHALL CONSTITUTE THE SOLE AND EXCLUSIVE REMEDY FOR BREACH OF WARRANTY, AND THE SUPPLIER SHALL NOT BE RESPONSIBLE FOR ANY INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES, OR LOST PROFITS OR THE COST OF REPAIRING OR REPLACING OTHER PROPERTY WHICH IS DAMAGED IF THE PRODUCT DOES NOT WORK PROPERLY.

4. Australian Consumer Law

This paragraph 4 applies if you are a 'Consumer' (as defined in section 3 of the Australian Consumer Law (**ACL**)) and the Product or services supplied to you falls within the goods or services which, for the purposes of the ACL, are of a kind ordinarily acquired for personal, domestic or household use or consumption.

The Products and services provided by the Supplier come with guarantees that cannot be excluded under the ACL, and noting in this Warranty Statement should be interpreted as attempting to exclude, restrict or modify such guarantees or your rights under the ACL. For major failures with any services, you are entitled:

- (c) to cancel your service contract with us; and
- (d) to a refund for the unused portion, or to compensation for its reduced value.

You are also entitled to choose a refund or replacement for major failures with Products. If a failure with the Product or a service does not amount to a major failure, you are entitled to have the failure rectified in a reasonable time. If this is not done you are entitled to a refund for the Products and to cancel the contract for the service and obtain a refund of any unused portion. You are also entitled to be compensated for any other reasonably foreseeable loss or damage from a failure in the Products or service*.

5. Warranty table

*the applicable period commences on the date of purchase of the Product.

PRODUCT GROUP	PRODUCT SERIES CODES	WARRANTY PERIOD (YEARS)*	LABOUR SUPPORT (YEARS)*
General Tapware, Spouts & Outlets- Chrome Plated	DET	10	2



1300 369 273
info@enware.com.au
enware.com.au